

## How to install a safe gas installation

Guidance on how to install a safe gas cooker installation in a small craft

ANCHOR MARINE SURVEYS

tim@anchormarinesurveys.co.uk Tel: 07973 836499

# A GUIDE ON HOW TO INSTALL A GAS COOKER

The following is a guide to the best practices on how to install a gas system and cooker on a small boat. It does not imply that these suggestions meet any particular LPG gas standards but are a collection of best practices from a number of standards as guidance only.

It is highly recommended that prior to the use of any new or altered LPG gas equipment that a safe gas registered LPG engineer carryout a gas safety check on the installation and issue a gas safety certificate to certify that it is safe to use.



## Or this may happen!!!



### **Diagram One**



# 1.4 Gas locker bulkhead head fitting

Where the gas supply passes into the gas locker a bulkhead compression fitting should be installed. This provides a gas vapour proof joint on the outside of the locker and a barbed hose tail fitting to on the inside of the locker to attach a flexible gas hose to.



1.5 Flexible gas hose in gas locker

Flexible hose used onboard boats should always be of High-Pressure LPG hose even if it is fitted to the low-pressure side of the system. There are a number of standards available in the EU however the only ones that should be fitted to boats are BS 3212/2 or BS *EN 16436* Class *3* (*Warning*!

Be careful I often see BS EN 16436 Class 2 hose fitted to boats and this is not for high pressure supplies).

Flexible hoses in a gas locker can be connected to a barbed push fit hose tail and secured with a correctly sized stainless-steel hose clamp. Due to the small diameter of this, it is best to use clamp that evenly secures the hose tail as the example below.



1.6	Securing Strap	Gas cylinders need to be always held in an upright position. In addition to this a sailing vessel needs to have the cylinder held securely down in the event that the vessel be knocked down in rough weather.
1.7	Grating	To prevent the cylinders from corroding and to encourage free drainage of any escaped gas the bottom of the locker should be fitted with a grate to lift the base of the cylinder above the locker sole.
1.8	Gas locker drain	The drain to the locker should be either in the base of the locker if this is not possible then it can be mounted on the side of the locker but no more than 25mm from the bottom. The hose connecting the locker drain to the skin fitting should be a straight fall with no loops or restrictions. The hose should have the same fire resistance as the gas locker. The inside diameter of the drain is dependent on the size of the cylinders that the locker contains however, the minimum requirements for a single cylinder is an ID of 19mm. The bigger the drain hole the more gas it can drain!
1.9	Drain skin fitting	The skin fitting hull outlet for the drain must not be below the waterline and be at least 75mm above the vessels resting waterline and if on a sailing vessel though the transom.
1.10	Pressure Release valve	Annex M regulators have an elbowed extension on the pressure release valve. This must always be pointed in a downward direction so that no water can get down inside the regulator.

### YACHT TIP ON INSTALLING AN LPG GAS COOKER



1.11	Cylinder Valve	All gas cylinders used on boats should be fitted with an isolation valve so that the gas supply can be closed at the point of exiting the cylinder.
1.12	Locker catch	Whilst not a statuary requirement it is prudent to always fit the gas locker lid with a method of securing it to prevent theft of the cylinder or unauthorised access.
1.13	Regulator	Regulators used in a saltwater environment should meet the EN12864 Annex M – ISO standards. The (Annex M) refers to marine. The reason for this is that standard regulators corrode in a salt damp environment and they can fail therefore allowing high pressure gas to enter the low- pressure supply which is not designed for these pressures and either leaks or can course a major flare up in a gas hob.
1.14	Label	The gas locker should always be clearly labelled
1.15	Regulator Nut	Some gas regulators use a nut to connect the regulator to the cylinder these are often an unusual size and have reverse threads and a suitable spanner should be located within the locker with a leash line so that changing the cylinder can be under taken easily and by feel.

#### **Diagram Two**



# Reference Notes to Diagram One

2.1 Hob with Flame protection device

All open flame LPG gas devices should have flame detection device fitted so that should the flame be blown out the gas supply is cut off. Some older cookers may not have these fitted and whilst it is not illegal to use these or a statuary requirement for the cookers to be updated. If used they should not be left unattended when in use.

Flame detection devices also need to be routinely checked to see that are working. The easiest way of doing this is light each burner in turn and once the device is warmed and the hub will run without holding in the bypass valve is to turn off the hob and listen for a click from the hob which is the device closing off the supply. If you then turn on the gas the supply should be off. The timing of these devices shut off varies with the temperature of the sensor so if it's been in use for a while, it will take longer to cool and shut off however anything over 20 sec's could mean the device is worn

### YACHT TIP ON INSTALLING AN LPG GAS COOKER

and needs renewing and should be checked over by a qualified LPG safe gas engineer.

- **2.2** Pan holders Cookers on boats used whilst at sea should be fitted with pan holders for safe reasons.
- 2.3 Oven Gimbals If the cooker is fitted with Gimbals the gimbal hinges should be fitted with stops to prevent the cooker from falling out of the hinges in the event of a knock down or inversion.

<sup>2.4</sup> Pressure test point So that the system can be pressure tested for leaks without breaking into the supply piping. A pressure test point should be fitted to the rear of the cooker.



2.5 Armoured Flexible supply hose

Any flexible hosing used outside of the gas locker must be fitted with factory fitted swaged ends and be no more than one meter in overall length and be of an approved LPG standard. Additional to this, it is also good practice to always use armoured hose on any cooker that is gimbaled. There are a number of standards available in the EU however the only ones that should be fitted to boats in the UK are BS 3212/2 or BS *EN* 16436 Class 3 (Warning! Be careful I often see BS *EN* 16436 Class 2 hose fitted to boats and this is not for high pressure supplies). (Please note barbed hose connections with worm drive clips are not permitted within the hull cavity).



2.6 Compression Joints

See item 3 in section one

- 2.7 Bulkheads Where the supply piping passes through a bulkhead it is important to make sure the rigid copper piping is protected from the bulkhead material by a rubber or plastic gromet to protect the copper pipe from abrasion. Alternatively, a compression bulkhead fitting can be used however this does add addition connects within the system with the additional risk of failure.
- 2.8 Oven Gimbal Lock

A cooker fitted with gimbals should also be fitted with a stop to prevent the cooker from rocking when not in use.



2.9	Rigid Gas Supply pipe	See item 1.2
2.10	Pipe Saddles	See 1tem 1.1